

Cantilever Brakes

Instruction Manual

BC001

Please read all instructions before installing and using your brakeset.

Be sure to install your brakes in a position where the pad makes contact with the rim only. Repetitive tire contact may lead to failure and costly repairs or injury.

Warning

Failure to install brakes properly may result in serious injury/death and or damage to your bicycle.

Fig 1





Fig 2



Installation

1. Place the caliper arm onto the brake boss on the frame/fork making sure to insert the tension pin into the center hole of the mounting boss. (Figure 1)
2. Insert bolt through caliper arm and into brake boss and tighten to 5-7Nm using a 5mm hex wrench. (Not Included)
3. Repeat steps 1 and 2 for other side.
4. Thread brake cable through the link wire, and clamp to the caliper arm as shown. (Figure 2)
5. Place the fixed end of the link wire in the hooked cable retainer cut out of the caliper arm.
6. Adjust brake cable tension so that the brake pads are approximately 2 - 3mm away from the rim surface on each side - Further adjustments can be made by utilizing a different tension pin mounting hole as well as turning the tension adjustment screw.
7. Depress the brake lever several times, fully engaging the brake, and check for play or stretch in the cable, making adjustments as necessary.

Brake cable stretch is normal after initial use and adjustments will be necessary. Always check that the brakes and other systems are working properly prior to riding.

SUNLITE